DESCRIPTION

Component Location: Transaxle case



Functions

- Output speed sensor : Detect the output shaft rpm(T/F DRIVEN GEAR RPM) at the T/F driven gear.
- Feedback control, clutch-clutch control, damper clutch control, shift range control, incorrect ratio control and sensor trouble detection signal.

transmissionmanuals.com