DCT(Dual Clutch Transmission) System / Dual Clutch System

transmissionmanuals.com

- Dual Clutch Assembly
- Clutch Engagement Fork and Engagement Bearing

Transmission Gear Oil

Repair procedures Inspection Oil level check 1. Remove the under cover. (Refer to Engine Mechanical System - "Engine Room Under Cover") 2. ...

Dual Clutch Assembly

Components and components location Components 1. Retaining ring 2. Spline hub 3. Snap ring 4. Dual clutch assembly Video Clip Dua ...

Other information:

Kia Forte 2019-2023 (BD) Service Manual: Electric Waste Gate Actuator (EWGA)

Specifications Specification Item Specification Motor , Supply Voltage (V) 13.5 Supply Voltage Range (V) 9 - 16 Max. Current (A) < 8.5 ...

Kia Forte 2019-2023 (BD) Service Manual: Steering wheel

Components and components location Components 1. Bezel 2. Remote control switch 3. Steering wheel

4. Dynamic damper 5. Extension wiring 6. Lower cover Repair procedures Removal and Installation 1. Disc ...

transmissionmanuals.com