PUBLISHED: 11-MAY-2011
2017.0 DISCOVERY (LR), 307-02

TRANSMISSION/TRANSAXLE COOLING - VEHICLES WITH: 8HP45 8-SPEED AUTOMATIC TRANSMISSION AWD

DIAGNOSIS AND TESTING

PRINCIPLE OF OPERATION

For a detailed description of the automatic transmission cooling system, refer to the relevant Description and Operation sections in the workshop manual. REFER to: Transmission Cooling (307-02 Transmission/Transaxle Cooling - 3.6L (TdV8) Diesel, Description and Operation).

INSPECTION AND VERIFICATION

1. Verify the customer concern by operating the system.

1. Visually inspect for obvious signs of damage and system integrity.

Visual Inspection

MECHANICAL
▪ Feed and return tubes ▪ Connections to the automatic transmission and the automatic transmission fluid cooler ▪ Automatic transmission fluid level

1. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step.

transmissionmanuals.com

1. If the cause is not visually evident, verify the symptom and refer to the Symptom Chart, alternatively check for Diagnostic Trouble Codes (DTCs) and refer to the DTC Index.

SYMPTOM CHART

CONDITION	POSSIBLE CAUSES	ACTION
Over heating of the automatic transmission	Obstruction in the automatic transmission fluid cooler	Flush out the automatic transmission fluid cooler with new automatic transmission fluid. If the flushing is unsuccessful, install a new transmission fluid cooler.
Over heating of the automatic transmission	Obstruction in the automatic transmission fluid tubes	Flush out the automatic transmission fluid cooler tubes with new automatic transmission fluid. If the flushing is unsuccessful install new automatic transmission fluid cooler tubes.
Loss of automatic transmission fluid	Connections to the automatic transmission and the automatic transmission fluid cooler	Check the integrity of the tubes, connections and seals. Check the torque of the tube fixings.
Loss of automatic transmission fluid	Leak at oil cooler	Check the integrity of tubes, connections and seals. Check the torque of the tube fixings.

DTC INDEX

For a list of Diagnostic Trouble Codes (DTCs) that could be logged on this vehicle, please refer to Section 100-00. REFER to: Diagnostic Trouble Code (DTC) Index - DTC: Module Name: Transmission Control Module - Bosch (100-00, Description and Operation).

transmissionmanuals.com