PUBLISHED: 30-MAR-2017
2017.0 DISCOVERY (LR), 308-07

TRANSFER CASE - [+] SINGLE SPEED TRANSFER CASE

TRANSFER CASE - V6 S/C 3.0L PETROL (G1972532)

REMOVAL

41.20.25	TRANSFER GEARBOX - RENEW	3000 CC, AJ V6 (AJ126), SINGLE SPEED TRANSFER CASE	4.2	USED WITHINS	
41.20.25	TRANSFER GEARBOX - RENEW	3000 CC, AJ V6 (AJ126), TWIN SPEED TRANSFER CASE	4.2	USED WITHINS	

REMOVAL

SPECIAL TOOL(S)

transmissionmanuals.com



303-1069

Adapter, Wrench

GENERAL EQUIPMENT

EQUIPMENT NAME
Transmission jack

PART(S)

STEP	PART NAME	QUANTITY
Step 7	Driveshaft flange bolts	1
Step 14	Transfer case front output shaft oil seal	1

CAUTION:

Before disconnecting any components, make sure the area is clean and free from foreign material. When disconnected all openings must be sealed.

transmissionmanuals.com

NOTE:

Some variation in the illustrations may occur, but the essential information is always correct.

1. Disconnect the battery ground cable.
   Refer to: Specifications (414-00 Battery and Charging System - General Information, Specifications).


2. **WARNING:**

   Make sure to support the vehicle with axle stands.

   Raise and support the vehicle.

3. Drain the transfer case fluid.
   Refer to: Transfer Case Draining and Filling (308-07 Transfer Case - Vehicles With: Single Speed Transfer Case, General Procedures).

4. Remove the transmission support crossmember.
   Refer to: Transmission Support Crossmember - V6 S/C 3.0L Petrol (502-02 Full Frame and Body Mounting, Removal and Installation).

5. 

   Remove the transfer case damper


transmissionmanuals.com

6. Remove the rear driveshaft.
Refer to: Rear Driveshaft - V6 S/C 3.0L Petrol (205-01 Driveshaft, Removal and Installation).

7.

CAUTION:


Mark the position of the driveshaft flange in relation to the drive pinion flange.



Renew Part: Driveshaft flange bolts Quantity: 1 .


transmissionmanuals.com

8.




Remove the earth strap.

9.



Release the wiring harness.


10.



11.

CAUTION:

Always plug any open connections to prevent contamination.




Remove the breather pipe.

transmissionmanuals.com

12.


WARNING:

Secure the component to the transmission jack.



General Equipment: Transmission jack

13.




Special Tool(s): 303-1069

transmissionmanuals.com

14.

CAUTION:

Do not carry out this step if a new transfer box is to be installed.



Remove and discard the O-ring seal.

Renew Part: Transfer case front output shaft oil seal Quantity: 1 .

transmissionmanuals.com