PUBLISHED: 21-NOV-2016
2017.0 DISCOVERY (LR), 308-07

TRANSFER CASE - [+] SINGLE SPEED TRANSFER CASE

TRANSFER CASE FRONT OUTPUT SHAFT BEARING (G1947974)

REMOVAL AND INSTALLATION

41.20.08	BEARING - FRONT OUTPUT SHAFT - RENEW	3000 CC, AJ V6 (AJ126), SINGLE SPEED TRANSFER CASE	5	USED WITHINS	
41.20.08	BEARING - FRONT OUTPUT SHAFT - RENEW	3000 CC, AJ V6 (AJ126), TWIN SPEED TRANSFER CASE	5.9	USED WITHINS	

transmissionmanuals.com

SPECIAL TOOL(S)

205-818

Installer, Seal



308-620

Installer, Seal



308-636

Installer




transmissionmanuals.com



JLR-308-926

Support Tool, Transfer Case



JLR-308-933

Remover, Transfer Case Flange

transmissionmanuals.com

PART(S)

STEP	PART NAME	QUANTITY
Installation Step 2	Transfer case front output shaft bearing	1
Installation Step 3	Transfer case front output shaft oil seal	1
Installation Step 4	Transfer case front output shaft snap ring	1

REMOVAL

NOTE:

- Some variation in the illustrations may occur, but the essential information is always correct.
- Some components shown removed for clarity.

1. Disconnect the battery ground cable.
   Refer to: Specifications (414-00, Specifications).

2. **WARNING:**

   Make sure to support the vehicle with axle stands.

   Raise and support the vehicle.

3. Drain the transfer case fluid.
   Refer to: Transfer Case Draining and Filling (308-07, General Procedures).

4. Remove the transfer case.
   Refer to: Transfer Case - TDV6 3.0L Diesel (308-07B, Removal).
   Refer to: Transfer Case - V6 S/C 3.0L Petrol (308-07B, Removal).
   Refer to: Transfer Case - INGENIUM I4 2.0L Diesel (308-07B, Removal).

transmissionmanuals.com

5.

CAUTION:

Make sure the bolt holes are clean and free of foreign materials.



Remove the 17 transfer box case bolts.

transmissionmanuals.com


6.

WARNING:

Eye protection must be worn.


CAUTION:

Care must be taken to avoid damage to the mating surfaces.



Using a soft faced mallet, release the rear casing.

7.



Split the transfer box case.

transmissionmanuals.com

8.

CAUTION:

Make sure that the mating faces are clean and free of foreign material.

Remove the sealant from the transfer case mating faces.

9.

CAUTION:

Note the installed position of the component prior to removal.




transmissionmanuals.com

10.

CAUTION:

Note the installed position of the component prior to removal.




Remove the transfer case chain assembly.

transmissionmanuals.com

11.

CAUTION:


Note the installed position of the component prior to removal.



Remove the spacer.

transmissionmanuals.com

12.



Install the special tool.

Special Tool(s): JLR-308-926

transmissionmanuals.com

13.

CAUTION:

Make sure that the special tool is correctly located. This will make sure that the snap ring is fully compressed during the next step.



Release the snap ring using the special tool.
Special Tool(s): JLR-308-933

transmissionmanuals.com

14.

CAUTION:

- Do not use excessive force whilst removing the flange assembly.
- Discard the snap ring.



Remove the transfer case front output shaft.
Special Tool(s): JLR-308-933

15.



Remove and discard the seal.

transmissionmanuals.com

16.



Remove the bearing.

INSTALLATION

1.




Position the special tool as shown, to support the transfer case during the next step.
Special Tool(s): JLR-308-926

transmissionmanuals.com

2.

CAUTION:

- The chamfer on the bearing inner track must face the seal.
- The transfer case must be supported by the special tool on a flat surface during this step.



transmissionmanuals.com

- Install the bearing.
  Special Tool(s): 308-620
- *Renew Part: Transfer case front output shaft bearing Quantity: 1 .*

3.



- Install the seal.
  Special Tool(s): 308-636
- *Renew Part: Transfer case front output shaft oil seal Quantity: 1 .*

transmissionmanuals.com

4.



- Centralize the snap ring in the snap ring groove before installing the output flange.
- Extreme care is necessary to make sure the snap ring enters the bearing squarely.
- Install a new snap ring.
- Using the special tool and with assistance, install the drive flange. *Special Tool(s):* 205-818
- *Renew Part: Transfer case front output shaft snap ring Quantity: 1* .

transmissionmanuals.com

5.

NOTE:

Make sure that the component is installed to the noted removal position.



Install the spacer.

transmissionmanuals.com


6.

CAUTION:

The dark links in the chain face up as shown.

NOTE:

Make sure that the components are installed to the noted removal position.




Install the transfer case chain assembly.

transmissionmanuals.com

7.

NOTE:


Make sure that the component is installed to the noted removal position.



E156807


transmissionmanuals.com

8.



Apply a 2 mm bead of sealant to one surface of the transfer case mating face, as shown.
Refer to: Specifications (308-07A, Specifications).

9.




transmissionmanuals.com

10.

CAUTION:

Only tighten the bolts finger-tight at this stage.



Install the 17 transfer box case bolts.


11.



Torque: **10 Nm**

transmissionmanuals.com

12.



Torque: **35 Nm**

13. Install the transfer case.
Refer to: Transfer Case - TDV6 3.0L Diesel (308-07B, Installation).
Refer to: Transfer Case - V6 S/C 3.0L Petrol (308-07B, Installation).
Refer to: Transfer Case - INGENIUM I4 2.0L Diesel (308-07B, Installation).

14. Fill the transfer case with the recommended fluid.
Refer to: Transfer Case Draining and Filling (308-07, General Procedures).

15. Connect the battery ground cable.
Refer to: Specifications (414-00, Specifications).

transmissionmanuals.com