Contents

	Advance Information		iii
1.	General		1.1/1
1.1	Illustration of transmission		1.1/1
1.2	Power flow diagram		1.2/1
1.3	Specifications		1.3/1
	1.3.1 Screw specifications		1.3/1
	1.3.1.1 Mechatronic type E		1.3/1
	1.3.1.2 Mechatronic type M		1.3/1
1.4	Adjusting procedure		1.4/1
	1.4.0 Measuring clutch packs	(procedure)	1.4/1
	1.4.1 Clearance setting, brake C	(snap ring)	1.4/3
	1.4.2 Clearance setting, brake D	(snap ring)	1.4/5
	1.4.3 Clearance setting, clutch B	(snap ring)	1.4/7
	1.4.4 Clearance setting, clutch A	(snap ring)	1.4/9
	1.4.5 Clearance setting, clutch E	(snap ring)	1.4/11
	1.4.6 Clearance - output	(disk)	1.4/13
	1.4.7 Clearance - input	(disk)	1.4/14
	(M type only)		
	1.4.8 Switch setting	(detent spring)	1.4/15
1.5	Tightening torques		1.5/1
1.6	Transmission test (test bench)		1.6/1
1.7	Special tools		1.7/1
1.8	Oilflow chart (Position N)		1.8/1
	(E - type)		1.8/1
	(M - type)		1.8/2
2.	Disassembly		2.1/1
2.1	Transmission disassembly according to component groups		2.1/1
	Dismantling		
2.2	Turret (with clutches A and E)		2.2/1
2.3	Oil supply		2.3/1
2.4	Clutch B		2.4/1
2.5	Brakes C and D		2.5/1
2.6	Output shaft with parking lock		2.6/1
2.7	Transmission casing with shift–control and parking lock		2.7/1
3.	Assembly		3.1/1
3.1	Transmission casing with shift control and parking lock		3.1/1
3.2	Output shaft with parking lock and planetary gear set		3.2/1
3.3	Brakes C and D		3.3/1
3.4	Clutch B		3.4/1
3.5	Turret (drive with clutches A and E)		3.5/1
	3.5.1 Clutch E (drive)		3.5/1
	3.5.2 Clutch A (input)		3.5/4
3.6	Oil supply		3.6/1
3.7	Mechatronics, oil pan and converter		
	(Complete mechatronics, see spare parts list, technical cover sheet, item YO2)		3.7/1

transmissionmanuals.com

Transmissionmanuals.com