## DESCRIPTION

- **Component**



- **Mounting location :** Control shaft complete is mounted on the top of the manual transaxle, and select & shift cable are equipped.
- **Function :** Change the gear by shifting a shift lever.

transmissionmanuals.com