DESCRIPTION

- **Components location :** Manual transaxle case
- **Operation principle :** Back up lamp switch is pushed by the reverse lug sliding when select arm, and switches the back up lamp.
- **Function :** Turn on the back up lamp when reversing.

transmissionmanuals.com