

2013 Chevrolet Colorado

Submodel: | Engine Type: | Liters:
Fuel Delivery: | Fuel:


Special Tools

DT-47928 Rear Seal Installer

For equivalent regional tools, refer to Special Tools.

[Removal Procedure](#)


1. Remove the rear propeller shaft. Refer to One-Piece Propeller Shaft Replacement or Two-Piece Rear Propeller Shaft Replacement.



2. Using a suitable tool, remove the rear transmission housing oil seal (1) from the transmission housing.

[Installation Procedure](#)

1. Coat the NEW seal lip with the recommended fluid.



2. Using the DT-47928 Rear Seal Installer and a hammer, install the NEW rear transmission housing oil seal (1).
3. Check the transmission fluid level. Add if necessary. Refer to Transmission Fluid Level Inspection.
4. Install the rear propeller shaft. Refer to One-Piece Propeller Shaft Replacement or Two-Piece Rear Propeller Shaft Replacement.