


2013 Chevrolet Colorado

Submodel: | Engine Type: | Liters:

Fuel Delivery: | Fuel:



Output Shaft Seal Removal

Callout

Component Name

1

Output Shaft Seal

Tip: Use pry bar or screwdriver to remove the oil seal and discard. The seal is not reusable.