






2013 Chevrolet Colorado

Submodel: | Engine Type: | Liters:
Fuel Delivery: | Fuel:

Illustration	Tool Number/Description
	DT 3289-20 J 3289-20 Holding Fixture Base Assembly
	DT 8763-B J 8763-B Holding Fixture
	DT 23129 J 23129 Universal Seal Remover
	DT 35512 J 35512 Inner Pinion Bearing Installer
	DT 36850 Transjel Lubricant
	DT 38416-B J 38416-B Harmonic Balancer Remover
	DT 38693 J 38693 Seal Installer

Illustration


Tool Number/Description



DT 38734

J 38734

Intermediate Spring Compressor Adapter



DT 41623-B

J 41623-B

KM 41623-B


Cooler Quick Connect Tool



DT 43074

J 43074

Clutch Spring Compressor



DT 45012

J 45012


Holding Fixture



DT 45096

J 45096

Transmission Oil Cooling System Flush and Flow Test Tool



DT 45096-30

J 45096-30


Transmission Cooler Flush Adapter



DT 45096-40

J 45096-40






Transflow Oil Fill Adapter



DT 45124

J 45124

Remover Bridge


Illustration	Tool Number/Description
	DT 45126 J 45126 Snap Ring Pliers
	DT 45201 J 45201 Cooler Line Seal Remover
	DT 46664 J 46664 Pump Cover Alignment Tool
	DT 47605 Holding Fixture Adapter
	DT 47715 Electrical Connector Passage Sleeve Remover/Installer
	DT 47731 1/2 Inch Quick Connect Release Tool
	DT 47761 Clutch Spring Compressor
	DT 47768-1 Seal Protector

Illustration


Tool Number/Description




DT 47768-2
Seal Pusher




DT 47768-3
Seal Sizer



DT 47770
Seal Installer




DT 47773
Snap Ring Pliers Adapter Set



DT 47778-1
Low Clutch Sprag Retaining Ring Cone



DT 47778-2
Low Clutch Sprag Retaining Ring Pusher




DT 47779
Clutch Spring Compressor



DT 47780
Low Clutch Sprag Seal Cone

Illustration

Tool Number/Description




DT 47781

C1234 and 35R Clutch Assembly Installer



DT 47782-1

Retaining Ring Cone




DT 47782-2

Retaining Ring Installer



DT 47784

Transmission Fluid Fill Pan Adapter




DT 47786

Output Carrier/Shaft Lifting Tool




DT 47825

Control Solenoid Test Plate



DT 47825-10

Jumper Harness




DT 47848

Seal Installer

Illustration


Tool Number/Description




DT 47857
Bearing Installer




DT 47865
Bearing Remover




DT 47866
Bearing Installer




DT 47867
Adjustable Clutch Spring Compressor




DT 47868-1
Pack Travel Weight



DT 47868-4
Clutch Travel Weight Adapter




DT 47868-2
Magnetic Base Adapter




DT-47868-3
Clutch Travel Weight Adapter

Illustration


Tool Number/Description



DT 48065
Clutch Spring Compressor




DT 48066-1A
Seal Sizer



DT 48066-2
Seal Pusher




DT 48066-3
Seal Protector




DT 48067
Holding Fixture Adapter



DT 48068-1
Low Clutch Sprag Retaining Ring Cone




DT 48068-2
Low Clutch Sprag Retaining Ring Pusher



DT 48069
Clutch Spring Compressor

Illustration


Tool Number/Description




DT 48070
Low Clutch Sprag Seal Cone



DT 48222
Bearing Installer



DT 48285
Valve Body Torx Plus Socket



DT-48989
Holding Fixture



DT-49122
Low Clutch Spring Compressor Adapter



DT 49291
Clutch Travel Air Passage Plug Kit




EN 28467-700
EN 47649
X-0206951
Engine Bridge Tool



GE 6125-B
J 6125-B
Slide Hammer

Illustration



Tool Number/Description

GE 8001

J 8001


Dial Indicator Set



GE 8092

J 8092


Driver Handle



GE 21867

J 21867

Pressure Gauge



GE 26900-13

J 26900-13

Magnetic Base



EL 38522

J 38522


Variable Signal Generator



EN 37212

J 37212


Front Output Shaft Seal Installer



EN 38869

J 38869

Output Shaft Seal Installer



EN 42183

J 42183

Driver Handle

Illustration



Tool Number/Description

EN 45000

J 45000

Seal Remover