


2013 Chevrolet Colorado

Submodel: | Engine Type: | Liters:

Fuel Delivery: | Fuel:



Transmission Output Shaft Seal Replacement

Callout

Component Name

Preliminary Procedure

Remove the case extension. Refer to Case Extension and Gasket Replacement.

Output Shaft Seal

Procedure

1

1. Use a suitable seal remover to remove the seal. Use care in order to avoid damaging the output shaft bushing.
2. Lubricate the seal with clean transmission fluid.
3. Use a suitable seal installer to install the seal.