

TRANSMISSION

Automatic Transmission - 6L50 (MYB) - Special Tools and Equipment - Special Tools - Canyon, Colorado

SPECIAL TOOLS AND EQUIPMENT

SPECIAL TOOLS

Illustration	Tool Number/Description
	DT 3289-20 J 3289-20 Holding Fixture Base Assembly

Illustration

**Tool
Number/Description**



DT 8763-B
J 8763-B
Holding Fixture

Illustration

**Tool
Number/Description**



DT 23129
J 23129
Universal Seal
Remover

Illustration




**Tool
Number/Description**

DT 35512
J 35512
Inner Pinion Bearing
Installer

Illustration

Tool
Number/Description



DT 36850
Transjel Lubricant


Illustration	Tool Number/Description
	DT 38416-B J 38416-B Harmonic Balancer Remover

Illustration	Tool Number/Description
	DT 38693 J 38693 Seal Installer

Illustration


**Tool
Number/Description**



DT 38734
J 38734
Intermediate Spring
Compressor Adapter

Illustration

**Tool
Number/Description**



DT 41623-B
J 41623-B
KM 41623-B
Cooler Quick
Connect Tool

Illustration


**Tool
Number/Description**



DT 43074
J 43074
Clutch Spring
Compressor

Illustration

**Tool
Number/Description**



DT 45012
J 45012
Holding Fixture

Illustration




**Tool
Number/Description**

DT 45096
J 45096
Transmission Oil
Cooling System
Flush and Flow Test
Tool

Illustration	Tool Number/Description
 The image shows two blue metal transmission cooler flush adapters. Each adapter has a long, straight body with a flared, multi-ported end at one side and a single threaded port at the other. The top adapter is labeled 'DT 45096-30' and the bottom one is labeled 'J 45096-30'. A diagonal watermark 'transmissionmanuals.com' is visible across the image.	DT 45096-30 J 45096-30 Transmission Cooler Flush Adapter

Illustration



**Tool
Number/Description**


DT 45096-40
J 45096-40
Transflow Oil Fill
Adapter

Illustration



**Tool
Number/Description**

DT 45124
J 45124
Remover Bridge


Illustration	Tool Number/Description
	DT 45126 J 45126 Snap Ring Pliers

Illustration

**Tool
Number/Description**



DT 45201
J 45201
Cooler Line Seal
Remover

Illustration	Tool Number/Description
 A blue, circular, ring-shaped tool, likely made of plastic or metal, used for aligning a pump cover. It has a thick, uniform rim and a central opening. The tool is shown from a slightly elevated perspective, casting a soft shadow on the surface below it. A faint watermark 'transmissionmanuals.com' is visible diagonally across the image.	DT 46664 J 46664 Pump Cover Alignment Tool

Illustration


**Tool
Number/Description**



DT 47605
Holding Fixture
Adapter


Illustration

**Tool
Number/Description**



DT 47715
Electrical Connector
Passage Sleeve
Remover/Installer

Illustration




Tool
Number/Description

DT 47731
1/2 Inch Quick
Connect Release Tool

Illustration	Tool Number/Description
	DT 47761 Clutch Spring Compressor

Illustration


**Tool
Number/Description**



DT 47768-1
Seal Protector

Illustration

**Tool
Number/Description**



DT 47768-2
Seal Pusher

Illustration

**Tool
Number/Description**



DT 47768-3
Seal Sizer


Illustration	Tool Number/Description
 A blue cylindrical tool, likely a seal installer, shown at an angle. It has a smooth, metallic finish and a slightly flared end. A watermark "transmissionmanuals.com" is visible diagonally across the image.	DT 47770 Seal Installer


Illustration

**Tool
Number/Description**



DT 47773
Snap Ring Pliers
Adapter Set





Illustration



**Tool
Number/Description**

DT 47779
Clutch Spring
Compressor

Illustration



**Tool
Number/Description**

DT 47780
Low Clutch Sprag
Seal Cone

Illustration



**Tool
Number/Description**

DT 47781
C1234 and 35R
Clutch Assembly
Installer


Illustration



Tool Number/Description

DT 47782-1 Retaining Ring Cone

Illustration




**Tool
Number/Description**

DT 47782-2
Retaining Ring
Installer

Illustration

Tool Number/Description



DT 47784 Transmission Fluid Fill Pan Adapter
--


Illustration

**Tool
Number/Description**




DT 47786
Output Carrier/Shaft
Lifting Tool


Illustration




Tool
Number/Description

DT 47825
Control Solenoid Test
Plate







Illustration


Tool Number/Description



DT 47865 Bearing Remover

Illustration

**Tool
Number/Description**



DT 47866
Bearing Installer

Illustration


Tool Number/Description




DT 47867 Adjustable Clutch Spring Compressor
--











Illustration

**Tool
Number/Description**



DT 48065
Clutch Spring
Compressor

Illustration




**Tool
Number/Description**


DT 48066-1A
Seal Sizer

Illustration

**Tool
Number/Description**




DT 48066-2
Seal Pusher




transmissionmanuals.com


Illustration



**Tool
Number/Description**

DT 48067
Holding Fixture
Adapter





Illustration



**Tool
Number/Description**


DT 48069
Clutch Spring
Compressor


Illustration

**Tool
Number/Description**



DT 48070
Low Clutch Sprag
Seal Cone






Illustration

**Tool
Number/Description**



DT-48989
Holding Fixture






Illustration

**Tool
Number/Description**




GE 6125-B
J 6125-B
Slide Hammer


Illustration





Tool
Number/Description

GE 8001
J 8001
Dial Indicator Set










Illustration

Tool Number/Description



EN 37212 J 37212 Front Output Shaft Seal Installer




Illustration

**Tool
Number/Description**



EN 42183
J 42183
Driver Handle

Illustration	Tool Number/Description
 A blue metal seal remover tool. It features a long, straight handle with a single bolt in the middle. The head of the tool is curved and has a notched edge, designed for prying or removing seals. The tool is shown against a white background with a faint watermark 'transmissionmanuals.com'.	EN 45000 J 45000 Seal Remover