



Last Modified: 12-21-2017	6.8:8.0.48	Doc ID: RM100000000T2ZR
Model Year Start: 2016	Model: LX570	Prod Date Range: [09/2015 -]
Title: AE80F AUTOMATIC TRANSMISSION / TRANSAXLE: AUTOMATIC TRANSMISSION UNIT: COMPONENTS; 2016 - 2018 MY LX570 [09/2015 -]		

COMPONENTS

ILLUSTRATION




ILLUSTRATION



*1	AUTOMATIC TRANSMISSION CASE PLUG	*2	MANUAL DETENT SPRING SUB-ASSEMBLY
*3	PARKING LOCK PAWL BRACKET	*4	PARKING LOCK PAWL SHAFT
*5	PARKING LOCK ROD SUB-ASSEMBLY	*6	REFILL PLUG
*7	TRANSMISSION REVOLUTION SENSOR (SP2)	*8	TRANSMISSION VALVE BODY ASSEMBLY
*9	TRANSMISSION WIRE	*10	VALVE BODY OIL STRAINER ASSEMBLY
*11	MANUAL DETENT SPRING COVER	*12	MANUAL VALVE LEVER SHAFT
*13	PARKING LOCK PAWL	*14	MANUAL VALVE LEVER SHAFT OIL SEAL
*15	MANUAL VALVE LEVER SUB-ASSEMBLY	*16	LOCK PLATE


*17	ATF TEMPERATURE SENSOR	*18	E-RING
*19	SPRING	*20	SPACER
*21	SPRING PIN	*22	O-RING
	N*m (kgf*cm, ft.*lbf): Specified torque	•	Non-reusable part
	MP Grease		Toyota Genuine ATF WS

ILLUSTRATION




ILLUSTRATION

OVERDRIVE AND REVERSE MULTIPLE DISC CLUTCH ASSEMBLY:




ILLUSTRATION


FORWARD MULTIPLE DISC CLUTCH ASSEMBLY:



ILLUSTRATION



ILLUSTRATION



ILLUSTRATION

DIRECT MULTIPLE DISC CLUTCH ASSEMBLY:

