

Last Modified: 12-21-2017	6.8:8.0.48	Doc ID: RM100000000T303
Model Year Start: 2016	Model: LX570	Prod Date Range: [09/2015 -]
Title: JF2A TRANSFER / 4WD / AWD: TRANSFER SYSTEM: DTC CHECK / CLEAR; 2016 - 2018 MY LX570 [09/2015 -]		

DTC CHECK / CLEAR

1. CHECK DTC

- (a) Check for DTCs.
 - (1) Turn the engine switch off.
 - (2) Connect the Techstream to the DLC3.
 - (3) Turn the engine switch on (IG).
 - (4) Turn the Techstream on.
 - (5) Read the DTCs following the prompts on the Techstream screen. Enter the following menus: Powertrain / Four Wheel Drive / Trouble Codes.
 - (6) Check the details of the DTCs (See page [INFO](#)).

2. CLEAR DTC

- (a) Clear the DTCs.
 - (1) Turn the engine switch off.
 - (2) Connect the Techstream to the DLC3.
 - (3) Turn the engine switch on (IG).
 - (4) Turn the Techstream on.
 - (5) Operate the Techstream to clear the DTCs. Enter the following menus: Powertrain / Four Wheel Drive / Trouble Codes.
 - (6) According to the display on the Techstream, select the trouble code data display with the clear button.