
# CIRCUIT DIAGRAM





[Connection Information]

| Terminal | Connected to | Function |
|---|---|---|
| 1 | TCM (71) | Overdrive Clutch, Low&Reverse Brake Control Solenoid Valve |
| 2 | TCM (72) | 24Brake Control Solenoid Valve |
| 3 | TCM (26) | ON/OFF Solenoid Valve |
| 4 | TCM (27) | Damper Clutch Control Solenoid Vave |
| 7 | TCM (3) | Ground |
| 8 | TCM (94) | Underdrive Clutch Control Solenoid Vave |
| 9 | TCM (93) | Line Pressure Control Solenoid Valve |
| 10 | TCM (70) | Ground |

[Harness Connector]




Solenoid Valve



TCM Connector

transmissionmanuals.com