
# CIRCUIT DIAGRAM

[Circuit Diagram]





[Connection Information]

| Terminal | Connected to | Function |
|---|---|---|
| 5 | TCM (80) | Oil temperature sensor (-) |
| 6 | TCM (57) | Oil temperature sensor (+) |

[Harness Connector]




Solenoid Valve Connector



TCM Connector

transmissionmanuals.com