
COMPONENTS



transmissionmanuals.com

Torque : N.m (kgf.m, lb-ft)

1. Radiator assembly	4. Radiator upper hose
2. Mounting insulator	5. Radiator lower hose
3. Radiator upper mounting bracket	6. Filler neck assembly