DESCRIPTION

Inhibitor switch monitors the lever's position(P, R, N, D, 3, 2, L) and is used to control gear setting signals.



transmissionmanuals.com