
Description

Clutch operation is detected through clutch switch signal. This signal enables ECM to cope with instant change of load condition.

Clutch switch signal is used to detect engaged gear with vehicle speed and engine speed.



Rate this Document

- Document Type : SHOP
- Document Rating :

Please rate the above contents on a scale of 1 to 5.

Little Value 1 2 3 4 5 Excellent Value

transmissionmanuals.com