
Components



Tightening torque : N.m (kgf.m, lb-ft)

1. Clutch pedal assembly
2. Clutch pedal arm
3. Ignition lock & Clutch switch
4. Clutch master cylinder
5. Reservoir hose
6. Clutch regulator
7. Clutch tube & pipe

transmissionmanuals.com

Rate this Document
Document Type : SHOP
Document Rating :

Please rate the above contents on a scale of 1 to 5.

Little Value 1 2 3 4 5 Excellent Value

transmissionmanuals.com