1.4 Adjusting procedure
1.4.0 Measuring clutch packs (procedure)

Place the two intermediate pieces 5p01 050 329/5p01 060 329 on the marked position on measuring fixture 5p01 000 330.



98009



98011



98012

Transmissionmanuals.com



98017



98018

Transmissionmanuals.com

Read the measurement value ➪ $\mathbf{M_X}$

Note!
In each case, the **X** index in $\mathbf{M_X}$ stands for the brake/ clutch clutch packs that are put in (A, B, C, D, E).