
DESCRIPTION

- **Component location :** Clutch switch is connected to top of the clutch pedal assembly.



- **Function**

1) Clutch operation is detected through clutch switch signal. This signal enables ECM to cope with instant change of load condition.
2) Clutch switch signal is used to detect engaged gear with vehicle speed and engine speed.

transmissionmanuals.com